




iDevices iGrill Battery Replacement

This guide will show you how to replace the batteries in the iGrill.

Written By: Kyle McElyea



INTRODUCTION

In this guide you will learn the step by step process of how to replace the batteries on an iGrill device.



TOOLS:


- [Fingers](#) (1)



PARTS:


- [AA Battery](#) (4)

Step 1 — Battery



- The back cover is accessible on the device by placing the screen in contact with a flat surface. Remove the back cover from the device.

Step 2



- Remove all dead or lowly charged batteries from the device.

Step 3



- Replace dead or poorly charged batteries with new AAs. After replacement of the batteries, put the back cover back on.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 02:36:50 AM.